








1. Press Switch 1 time for Bright 160 Lumen white light
2. Press Switch 2nd time for Eco Mode 50 Lumen white Light.
3. Press Switch 3rd time for 25 Lumen Red color Light.
4. Press Switch 4th time for Red Flashing Light (SOS MODE) -----
Press switch one more time and lamp will SWITCH-OFF
5. Press Switch continuously till the switch lights up, this will activate motion sensor – move your hand in front of light to switch on light and move second time to switch off light.
6. Light can be swiveled 360 degrees to direct light or can be moved 180 deg for the right direction.



1. Use As a Headlamp
2. Use as a Wrist Light or a Shoulder/Elbow Light.
3. There are 2 separate Fluorescent straps provided which glows once any light shines on it; and can be easily replaced depending on your need. Plastic housing where strap is attached has an inclined slot which allows for ease of removal of strap loop.
4. Remove strap all together to use it as a work light.
5. Remove strap altogether and you can use the clip on the housing to make it as book light, cap visor light, shirt light.
6. USB (Micro USB) Charging cable is provided with the Light for ease of recharging the battery. It takes 1.5 hours to fully charge battery from zero charge.
7. See below the slot in plastic housing



Lightest Light (58 gms)



Lift the black rubber flap and you can insert a C-type USB cable (included) to charge. If fully discharged, it will take about 1.5 hours to charge it. When fully charged red light will turn blue



Slot to help & guide to remove or insert strap/Band